

FIG. 1





			T			
/ 168	STATUS DISPLAY FLAG COLUMN	 1	1	0	1	
. 166	USER ATTRIBUTE COLUMN	 MANAGER	MANAGER OF CONSUMABLES	NORMAL USER	NORMAL USER	
164	IM MAIL ADDRESS COLUMN	 AAA@im	BBB@im	CCC@im	DDD@im	
60 / 162	STATUS	 -	0	1	<b>-</b>	
FIG. 3 160	COLUMN	 AAA	BBB	200	DDD	

114

156	THIRD DISPLAY CONTENTS COLUMN	 Called Incoming Call <transmitter> <date> <remaining memory=""></remaining></date></transmitter>	
154	SECOND DISPLAY CONTENTS COLUMN	Called <date> <remaining memory=""> Incoming Call <status> <number jobs="" of=""> <transmitter> <date></date></transmitter></number></status></remaining></date>	
	FIRST DISPLAY CONTENTS COLUMN	Called	
FIG. 4	STATUS CODE COLUMN	 0125	

128